

Manual for use

Item number: 28630

Model No.: PLYL-10F



Please read this manual carefully before using.



Technical specifications

Item	Hedge trimmer
Item No.:	28630
Model No.:	PLYL-10F
Rated voltage	20V
Max. cutting	15 mm
Stroke length	610 mm
Net weight	2.3 kg
No load speed	1300 min ⁻¹
Sound pressure level LpA	79 dB(A), K = 3 dB
Measured sound power level LwA	87 dB(A), K = 3 dB
Guaranteed sound power level LwA	90dB(A), K = 3 dB
Vibration level	A _{h,w} =1.1m/s ² , k=1.5 m/s ²

WARNING!


The actual vibration level when using power tools may differ from the specified maximum value, depending on how the tool is used. It is therefore necessary to determine which safety precautions are required to protect the user, based on an estimate of exposure in actual operating conditions (taking into account all stages of the work cycle, e.g. the time when the tool is switched off and when it is idling, in addition to the start-up time).

Always wear ear protection.

The declared vibration value, which has been measured by a standardised test method, can be used to compare different tools with each other and for a preliminary assessment of exposure.

Descriptions

- 1) Battery compartment
- 2) Shear blades
- 3) Lock button for rotatable handle
- 4) Switch trigger
- 5) Lock trigger



Manual for battery treatment

- Depending on the characteristics of the lithium battery, it is important to check the charge level after 3 months. If the charge level is low, you need to ensure the battery charge.
- If you leave the battery pack for a long time without charging, the charge level may drop to a very low level or the battery pack may discharge completely. In this case the battery may be damaged.
- After the battery pack is fully charged, it can be left unused for a long time. It is generally recommended to check the battery at least every 3 months.
- When using the cordless tools with batteries, please remember to charge the battery in time after use. Otherwise, the battery will be easy damaged.

Charging the battery

APPROXIMATE CHARGE TIMES WITH CHARGERS	
4000 mAh	
4 A quick charger (28086)	70 min.
2,4 A quick charger (28085)	90 min.
8000 mAh	
4 A quick charger (28086)	125 min.
2,4 A quick charger (28085)	240 min.

WARNING

Before preparing and using the cordless tool for use, read the entire instruction manual and keep it with the product so that the operator can familiarize himself with it.

If you lend or sell the product to anyone, enclose this instruction manual with it. Avoid damaging this manual. The manufacturer is not liable for damages or injuries caused by using the device, which is in conflict with these instructions. Before using the appliance, familiarize yourself with all its controls and components, as well as how to switch off the appliance, so that you can switch it off immediately in the event of a dangerous situation. Before use, check that all components are securely fastened and that any part of the device, such as the safety guards, is not damaged, incorrectly installed or missing in place. This also applies to the charger and its power cord. If the cordless tool, battery or charger is damaged or incomplete, do not use it and have it repaired or replaced with original parts. To check the battery charge level, press the button on the battery and, if necessary, charge the battery according to the number of LEDs and the expected operating time of the cordless tool. When the battery is fully charged, all LEDs are lit. The battery can be charged from any charge level without reducing its capacity.

- 1. Insert the battery into the slots of the supplied charger first.**
- 2. Before connecting the charger to a power source. current, check that the voltage in the socket corresponds to the range 220-240 ~ 50 Hz and that the charger does not have a damaged power cable (eg insulation) or cover or other part.**

If the charger is damaged, have it replaced by a faultless original one from the manufacturer. Only the original charger provided by the manufacturer must be used to charge the battery, otherwise the use of another charger may cause a fire or explosion due to unsuitable charging parameters. Protect the charger's power cord from damage.

3. Connect the charger to a wall outlet. current.


For 28085/28086 chargers

- when in charging process, it is indicated by a green flashing LED next to the red LED.
- when full charging, it is indicated only by a green LED on.
- when in abnormal charging process, it is indicated by both green and red flashing LED.
- The charge level of the battery can be monitored by the number of lit LEDs on the battery that light up when the battery is being charged. We reserve the right to change the above signaling of the charging and recharging process.

4. After charging, first disconnect the charger from the power source. power, and then slide the battery out of the charger slots by pressing and holding the button on the battery.

Description of battery functions

Display of remaining battery capacity



1. Indicator lamps 2. Check button

Indicator lamps			Remaining capacity
Lighted	Off	Blinking	
■ ■ ■ ■			75% to 100%
■ ■ ■ □			50% to 75%
■ ■ □ □			25% to 50%
■ □ □ □			0% to 25%
▣ □ □ □			Charge the battery.

Attaching or removing the battery



1. Button
2. Battery

Functional Description


CAUTION: Always be sure that the tool is switched off and the battery cartridge is removed before adjusting or checking function on the tool.

Angle setting of the handle

CAUTION: Always make sure that the handle is locked in the desired position before operation.

CAUTION: Do not pull down the lever to unlock the handle while pulling the switch trigger. Do not pull the switch trigger while pulling down the lever and turning the handle. Failure to do so may cause a malfunction of the tool.

You can set the angle of the handle to 0°, -90°, or 90° to the left or right. To change the angle of the handle, turn the handle while pulling back the lock button, and then release the lock button.



1. lock button

Power switch action

WARNING: For your safety, this tool is equipped with lock-off lever which prevents the tool from unintended starting. NEVER use the tool if it runs when you simply press the switch lever and pull the switch trigger without pressing the lock-off lever. Return the tool to our authorized service center for proper repairs BEFORE further usage.

WARNING: NEVER tape down or defeat purpose and function of lock-off lever.

WARNING: Before installing the battery cartridge on the tool, always check to see that the switch trigger and switch lever actuate properly and return to the "OFF" position when released. Operating a tool with a switch that does not actuate properly can lead to loss of control and serious personal injury.

CAUTION:

Never put your finger on the switch when carrying. The tool may start unintentionally and cause injury.

NOTICE: Do not pull the switch trigger hard without pressing the lock-off lever. This can cause switch breakage.

NOTE: The tool is automatically turned off if the tool is not operated for a certain period.

To prevent the switch trigger from being accidentally pulled, a lock-off lever is provided. To start the tool, one hand press the switch trigger and the other hand pull the lock trigger. The tool speed increases by increasing pressure on the switch trigger. Release the switch trigger to stop.



1. Lock trigger

2. Switch trigger

Electric brake

This tool is equipped with an electric brake.

ASSEMBLY:

CAUTION: Always be sure that the tool is switched off and the battery cartridge is removed before carrying out any work on the tool.

CAUTION: When replacing the shear blades, always wear gloves so that your hands do not directly contact the blades.

NOTICE: When replacing the shear blades, do not wipe off grease from the gear and crank.

Installing or removing the shear blades:

CAUTION: Attach the blade cover before removing or installing the shear blades.

CAUTION: Avoid operating the tool in very hot weather as much as practicable. When operating the tool, be careful of your physical condition.

CAUTION: Be careful not to accidentally contact a metal fence or other hard objects while trimming. The shear blades may break and cause an injury.

CAUTION: Be careful not to allow the shear blades to contact the ground. The tool may recoil and cause an injury.


CAUTION: Overreaching with a hedge trimmer, particularly from a ladder, is extremely dangerous. Do not work while standing on anything wobbly or infirm.

NOTICE: Do not attempt to cut branches thicker than 15 mm in diameter with the tool.


NOTICE: Do not cut down dead trees or similar hard objects. Doing so may damage the tool.

NOTICE: Do not trim the grass or weeds while using the shear blades. The shear blades may become tangled in the grass or weeds.


Hold the tool with both hands, press the switch lever and pull the switch trigger, and then move it forward.



For basic operation, tilt the shear blades toward the trimming direction and move it calmly and slowly at the speed rate of 3 to 4 seconds per meter.



To cut a hedge top evenly, tie a string at the desired height and trim along it.



MAINTENANCE

CAUTION: Always be sure that the tool is switched off and the battery cartridge is removed before attempting to perform inspection or maintenance.


Cleaning the tool

Clean the tool by wiping off dust with a dry cloth or one dipped in soapy water and wrung out.


NOTICE: Never use gasoline, benzine, thinner, alcohol or the like. Discoloration, deformation or cracks may result.

Shear blade maintenance

Before the operation or once per hour during operation, apply low-viscosity oil (machine oil, or spray-type lubricating oil) to the shear blades.



After operation, remove dust from both sides of the shear blades with a wired brush, wipe it off with a cloth and then apply low-viscosity oil (machine oil, or spray type lubricating oil) to the shear blades.




NOTICE: Do not wash the shear blades in water. Doing so may cause rust or damage to the tool.

NOTICE: Dirt and corrosion cause excessive blade friction and shorten the operating time per battery charge.


Grinding the shear blades

NOTICE: If the shear blades have considerably deformed by grinding, replace the shear blades with new ones.

1. Install the battery cartridge to the tool.
2. Turn on and start the tool so that the upper blade and lower blade are positioned alternately.




3. Turn off the tool and remove the battery cartridge from the tool.
4. Remove the screw, and then remove the branch catcher.



1. Screw 2 . Branch catcher


5. Set the angle of a file to 45°, and grind the upper blade from 3 directions with the file.



(1) File (2) 45°

CAUTION: Before grinding the shear blades, make sure that the tool is switched off and the battery cartridge is removed from the tool.

6. Place the tool upside down, and then remove the burrs from the shear blades with the file.



1. File

7. Set the angle of the file to 45°, and grind the lower blade from 3 directions with the file.

8. Return the tool to normal position, and then remove the burrs from the shear blades with the file.

9. Attach the branch catcher by tightening the screw.

Cordless Hedge Trimmer Safety Warnings

1. Keep all parts of the body away from the cutter blade. Do not remove cut material or hold material to be cut when blades are moving. Make sure the switch is off when clearing jammed material. Blades coast after turn off. A moment of inattention while operating the hedge trimmer may result in serious personal injury.
2. Carry the hedge trimmer by the handle with the cutter blade stopped. Proper handling of the hedge trimmer will reduce possible personal injury from the cutter blades.
3. Hold the power tool by insulated gripping surfaces only, because the cutter blade may contact hidden wiring. Cutter blades contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.
4. DANGER - Keep hands away from blade. Contact with blade will result in serious personal injury.

5. Do not use the hedge trimmer in the rain or in wet or very damp conditions. The electric motor is not waterproof.
6. First-time users should have an experienced hedge trimmer user show them how to use the trimmer.
7. The hedge trimmer must not be used by children or young persons under 18 years of age. Young persons over 16 years of age may be exempted from this restriction if they are undergoing training under the supervision of an expert.
8. Use the hedge trimmer only if you are in good physical condition. If you are tired, your attention will be reduced. Be especially careful at the end of a working day. Perform all work calmly and carefully. The user is responsible for all damages to third parties.
9. Never use the trimmer when under the influence of alcohol, drugs or medication.
10. Work gloves of stout leather are part of the basic equipment of the hedge trimmer and must always be worn when working with it. Also wear sturdy shoes with anti-skid soles.
11. Before starting work, check to make sure that the trimmer is in good and safe working condition. The hedge trimmer must not be used unless fully assembled.
12. Make sure you have a secure footing before starting operation.
13. Hold the tool firmly when using the tool.
14. Do not operate the tool at no-load unnecessarily.
15. Immediately switch off the motor and remove the battery cartridge if the cutter should come into contact with a fence or other hard object. Check the cutter for damage, and if damaged repair immediately.
16. Before checking the cutter, taking care of faults, or removing material caught in the cutter, always switch off the trimmer and remove the battery cartridge.
17. Switch off the trimmer and remove the battery cartridge before doing any maintenance work.
18. When moving the hedge trimmer to another location, including during work, always remove the battery cartridge and put the blade cover on the cutter blades. Never carry or transport the trimmer with the cutter running. Never grasp the cutter with your hands.
19. Clean the hedge trimmer and especially the cutter after use, and before putting the trimmer into storage for extended periods. Lightly oil the cutter and put on the cover. The cover supplied with the unit can be hung on the wall, providing a safe and practical way to store the hedge trimmer.
20. Store the hedge trimmer with the cover on, in a dry room. Keep it out of reach of children. Never store the trimmer outdoors.
21. Never point the shear blades to yourself or others.
22. If the blades stop moving due to the stuck of foreign objects between the blades during operation, switch off the tool and remove the battery cartridge, and then remove the foreign objects using tools such as pliers. Removing the foreign objects by hand may cause an injury for the reason that the blades may move in reaction to removing the foreign objects.
23. Avoid dangerous environment. Don't use the tool in damp or wet locations or expose it to rain. Water entering the tool will increase the risk of electric shock.
24. Do not dispose of the battery(ies) in a fire. The cell may explode. Check with local codes for possible special disposal instructions.
25. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
26. Do not charge battery in rain, or in wet locations.
27. Check the hedges and bushes for foreign objects, such as wire fences or hidden wiring before operating the tool.

General safety instructions for power tools



CAUTION!

All safety instructions, operating instructions, pictures and regulations supplied with this tool must be read. Failure to follow all of the following instructions may result in electric shock, fire, and / or serious personal injury.

All instructions and instructions for use must be kept for future reference.

The term "power tool" in all of the following warnings refers to a mains-operated (flexible power supply) or a battery-powered power tool (without a movable power supply).

1. SAFETY OF THE WORK ENVIRONMENT

- a) **Workplaces must be kept clean and well lit.** Clutter and dark spaces are often the cause of accidents.
- b) **Power tools must not be used in potentially explosive atmospheres where flammable liquids, gases or dust are present.** Power tools create sparks which may ignite the dust or fumes.
- c) **When using a power tool, keep out of the reach of children and others.** If the operator is disturbed, he may lose control of the activity being performed.

2. ELECTRICAL SAFETY

- a) **The plug of the power tool's flexible lead must match the power outlet. The forks must never be modified in any way. No socket adapters may be used with tools that have a protective earth connection.** Plugs that are not damaged by modifications and the corresponding sockets will reduce the risk of electric shock.
- b) **Operators must not touch grounded objects, such as pipes, central heating units, cookers and refrigerators.** The risk of electric shock is greater if your body is connected to the ground.
- c) **Power tools must not be exposed to rain, moisture or wetness.** If water enters the power tool, the risk of electric shock increases.
- d) **The flexible supply must not be used for other purposes. The power tool must not be carried or pulled by the power cord, nor must the plug be unplugged from the outlet. The inlet must be protected from heat, grease, sharp edges or moving parts.** Damaged or tangled leads increase the risk of electric shock.
- e) **If the power tool is used outdoors, an extension cord suitable for outdoor use must be used.** Using an extension cord for outdoor use reduces the risk of electric shock.
- f) **If the power tool is used in humid areas, a RCD protected power supply must be used.** Using an RCD reduces the risk of electric shock. The term "RCD" may be replaced by "main circuit breaker (GFCI)" or "leakage circuit breaker (ELCB)".

3. PERSONAL SAFETY

- a) **When using a power tool, the operator must be careful, pay attention to what he is doing, and concentrate and think soberly. Power tools must not be used if the operator is tired or under the influence of drugs, alcohol or medication.** Momentary inattention while using a power tool can result in serious personal injury.
- b) **Use personal protective equipment. Always wear eye protection.** Protective equipment such as a respirator, non-slip safety shoes, hard headgear or hearing protection, used in accordance with the working conditions, reduces the risk of personal injury.
- c) **Unintentional starting of the machine must be avoided. Make sure that the switch is in the off position before plugging in and / or connecting the battery pack, lifting or carrying the tool.** Carrying a tool with your finger on the switch or plugging in a tool fork with the switch on can cause accidents.
- d) **All adjusting tools or wrenches must be removed before turning on the tool.** An adjusting tool or wrench that remains attached to the rotating part of the power tool may result in personal injury.
- e) **The operator must only work where he can reach safely. The operator must always maintain a stable posture and balance.** This will allow better control of the power tool in unforeseen situations.
- f) **Dress appropriately. Do not wear loose clothing or jewelry. The operator must make sure that his hair and clothing are far enough away from moving parts.** Loose clothing,

jewelry and long hair can be caught in moving parts.

- g) **Where means are provided for the connection of dust extraction and collection facilities, care shall be taken to ensure that such equipment is connected and used correctly.** The use of these devices can reduce the hazards caused by dust.
- h) **The operator must not allow the routine, which is based on the frequent use of the tool, to become complacent and ignore the principles of tool safety.** Careless operation can cause serious injury in a fraction of a second.

4. USE AND MAINTENANCE OF BATTERY TOOLS

- a) **Power tools must not be overloaded. It is necessary to use the correct power tool that is intended for the work performed.** The right power tool will do the job it was designed to do better and safer.
- b) **Power tools that cannot be turned on and off with the switch must not be used.** Any power tool that cannot be operated with the switch is dangerous and must be repaired.
- c) **Before making any adjustments, changing accessories or storing power tools, unplug the power tool and / or remove the battery pack from the power tool, if removable.** These precautions reduce the risk of accidental starting of the power tool.
- d) **Unused power tools must be stored out of the reach of children and persons unfamiliar with the power tool or these instructions must not be allowed to use the power tool.** Power tools are dangerous in the hands of inexperienced users.
- e) **Power tools and accessories must be maintained. It is necessary to check the adjustment of moving parts and their mobility, focusing on cracks, broken parts and any other circumstances that may jeopardize the function of the power tool. If the tool is damaged, it must be repaired before further use.** Many accidents are caused by poorly maintained power tools.
- f) **Cutting tools must be kept sharp and clean.** Properly maintained and sharpened cutting tools are less likely to catch on the material or become jammed and easier to control.
- g) **Power tools, accessories and tool bits etc. must be used in accordance with these instructions and in the manner intended for the particular power tool, taking into account the working conditions and the work to be performed.** Using power tools for activities other than those for which they were designed can lead to dangerous situations.
- h) **Handles and grip surfaces must be kept dry, clean and free of grease.** Slippery handles and grip surfaces do not allow the tool to be held and inspected safely in unexpected situations.

5. USE AND MAINTENANCE OF BATTERY TOOLS

- a) **Charge the tool only with the charger specified by the manufacturer.** A charger that may be suitable for one type of battery pack may present a fire hazard when used with another battery pack.
- b) **Only use the tool with a battery pack that is specifically designed for the tool.** Use of any other battery pack may present a risk of injury or fire.
- c) **When the battery pack is not in use, protect it from contact with other metal objects such as paper clips, coins, keys, nails, screws, or other small metal objects that may cause one battery contact to connect with another.** Short-circuiting the battery terminals may cause burns or fire.
- d) **If used incorrectly, liquids may leak from the battery; avoid contact with them. In case of accidental contact with these liquids, rinse the affected area with water. In addition, seek medical attention if fluid gets in your eyes.** Liquids escaping from the battery can cause inflammation or burns.
- e) **A battery pack or tool that is damaged or rebuilt must not be used.** Damaged or modified batteries can behave unpredictably, which can result in fire, explosion, or risk of injury.

- f) **Battery packs or tools must not be exposed to fire or excessive heat.** Exposure to fire or temperature above 130 ° C may cause an explosion.
- g) **All charging instructions must be followed and the battery pack or tool must not be charged outside the temperature range specified in the operating instructions.** Improper charging or charging at temperatures outside this range may damage the battery and increase the risk of fire.

6. SERVICE

- a) **Have your cordless tool repaired by a qualified person using identical spare parts.** This will ensure the same level of tool safety as before repair.
- b) **Damaged battery packs must never be repaired.** Repairs to battery packs should only be performed by the manufacturer or an authorized service center.

Charger safety instructions



- Protect the charger from rain and moisture. The charger may only be used indoors.
- The charger is intended for charging only the battery supplied with this cordless tool and no other batteries. Charging batteries other than those for which the charger is intended may result in fire or explosion.
- Keep the charger clean.
- Before each use, check that the charger is in good condition, including the power cord.
- Do not operate the charger on highly flammable objects and substrates (eg paper) or in an environment with an explosive and / or flammable atmosphere.
- Always provide adequate ventilation when charging, as vapors or electrolyte may leak from the battery if the battery is damaged due to mishandling / damage.
- Do not operate the charger on highly flammable objects and substrates (eg paper) or in an environment with an explosive and / or flammable atmosphere.
- Always provide adequate ventilation when charging, as vapors or electrolyte may leak from the battery if the battery is damaged due to mishandling / damage.
- When charging is complete, disconnect the charger from the wall outlet. do not leave it connected to the power supply for longer than necessary.
- Avoid using the charger by persons (including children) whose physical, sensory or mental disability or lack of experience and knowledge prevents them from using the appliance safely without supervision or instruction. Children must not play with the appliance. In general, the use of the appliance by very young children (age 0-3 years inclusive) and use by younger children without supervision (age over 3 years under 8 years) are not taken into account. It is recognized that people with severe disabilities may have needs outside the level specified in this standard (EN 60335).

Battery safety instructions

- Store and charge the battery in a dry environment and make sure that no water enters it.
- Never expose the battery to direct sunlight or temperatures above 50 ° C.
- Charge the battery only for the time required for charging, see. indicator light on the charger.
- Keep the battery connectors clean and free from clogging, deformation and short circuits.
- Protect the battery from shocks, moisture and never open or mechanically damage the battery.

- Never incinerate, dispose of in water or the environment, but dispose of it in an environmentally friendly manner.
- Avoid skin contact if the battery is damaged and electrolyte leaks due to improper handling of the battery. If skin gets on, wash thoroughly with water. Liquids leaking from the battery can cause inflammation, burns, or burns. In case of contact with eyes, rinse thoroughly with clean water and consult a doctor immediately, in case of ingestion consult a doctor immediately about the procedure.

Storage

- Store cordless tools in a dry place out of the reach of children. For safety reasons, remove the battery before storing the cordless tool. When the battery is inserted in the cordless tool, it discharges faster. Protect the battery and tools from frost, high temperatures, humidity and water.

Meaning of symbols on labels



	Read the instructions before use.
	Use certified eye and ear protection with a sufficient level of protection.
	Wear protective gloves, and protect your hands from injury.
	Do not expose to rain.
	Keep at a safe distance.
	Be careful of splashes, bystanders stay away
	Meets relevant EU requirements.
	DC current/ voltage.
	Electrical waste, see below.
	Serial number including year, month of manufacture

Waste disposal

PACKAGING

- Dispose of the packaging in the appropriate waste container.

CORDLESS POWER TOOLS



According to the European Directive (EU) 2012/19, electrical and electronic equipment may not be disposed of as mixed waste, but it is necessary to return them for ecological disposal to the return of electrical equipment at designated collection points. Before returning the cordless tool, remove the battery, which must be disposed of in an environmentally friendly manner separately. You will receive information about collection points at the municipal office.

BATTERY



The battery contains cartridges that are dangerous for the environment, so return it to the batteries for ecological recycling / disposal. According to the European Directive on Accumulators and Batteries 2006/66 EC, unusable batteries must not be disposed of with mixed waste or the environment. You will receive information about collection points at the municipal office.

Warranty period and conditions (rights from defective performance)

- If the buyer so requests, the seller is obliged to provide the buyer with warranty conditions (rights from defective performance) in writing in accordance with the law.

WARRANTY AND POST-WARRANTY SERVICE

To exercise the right to warranty repair of the goods, contact the dealer from whom you purchased the goods.

EU Declaration of Conformity

Manufacturer Levior s.r.o. • Tovačovská 3488, CZ-750 02 Přerov declares that the subsequently marked devices, based on their concept and construction, as well as the designs listed on the market, meet the requirements of the European Union listed below. This declaration is issued under the sole responsibility of the manufacturer.

Subjects of declaration-product identification:

Cordless Hedge trimmer

Item. No.: 28630

Model No.: PLYL-10F

comply with the following harmonized standards, including their amending annexes, if any, by which conformity with the following harmonization provisions is declared:

2006/42/EC:

EN 62841-1:2015+A11

EN 62841-4-2 :2019+A1+A11

2014/30/EU:

EN IEC 55014-1:2021

EN IEC 55014-2:2021

The technical documentation (2006/42/EC and 2014/30/EU) is available at the manufacturer's address.

Place and date of issue of the EU declaration of conformity: Přerov, 15.12. 2025

Person authorized to draw up the EU declaration of conformity on behalf of the manufacturer

(signature, name, function):


Tovačovská 3488/28, 750 02 Přerov
IČO 61973939 DIČ CZ61973939
tel.: 581 746 256-8, fax: 581 746 255



Ondřej Marek

Managing director Levior s.r.o.

Návod použití

Číslo položky: 28630

Model č.: PLYL-10 F



Před použitím si přečtěte manuál.



Technické specifikace

Položka	Nůžky na živý plot
Číslo položky.:	28630
Model č.:	PLYL-10F
Jmenovité napětí	20V
Max. řez	15 mm
Délka zdvihu	610 mm
Čistá hmotnost	2.3 kg
Otáčky bez zatížení	1300 min ⁻¹
Hladina akustického tlaku LpA	79 dB(A), K = 3 dB
Naměřená hladina akustického výkonu LwA	87 dB(A), K = 3 dB
Garantovaná hladina akustického výkonu LwA	90dB(A), K = 3 dB
Hladina vibrací	A _{h,w} =1.1m/s ² , k=1.5 m/s ²

VAROVÁNÍ!


Skutečná úroveň vibrací při používání elektrického nářadí se může lišit od uvedené maximální hodnoty v závislosti na způsobu použití nářadí. Je proto nutné určit, jaká bezpečnostní opatření jsou potřebná k ochraně uživatele, a to na základě odhadu expozice za skutečných provozních podmínek (s přihlédnutím ke všem fázím pracovního cyklu, např. době, kdy je nářadí vypnuté nebo běží naprázdno, kromě doby rozběhu).

Vždy používejte ochranu sluchu.

Uvedená hodnota vibrací, která byla naměřena standardizovanou zkušební metodou, může být použita ke srovnání různých nářadí mezi sebou a k předběžnému posouzení expozice.

Popis

- 6) Prostor pro baterii
- 7) Střížné nože
- 8) Aretační tlačítko otočné rukojeti
- 9) Spoušť vypínače
- 10) Pojistka spouště



Návod k zacházení s baterií

- Vzhledem k vlastnostem lithiové baterie je důležité zkontrolovat úroveň nabití po 3 měsících. Pokud je úroveň nabití nízká, je nutné baterii dobít.
- Pokud ponecháte akumulátor delší dobu bez nabíjení, může úroveň nabití klesnout na velmi nízkou hodnotu nebo se akumulátor zcela vybijí. V takovém případě může dojít k jeho poškození.
- Po úplném nabití může být akumulátor ponechán delší dobu bez použití. Obecně se doporučuje kontrolovat stav baterie alespoň jednou za 3 měsíce.
- Při používání akumulátorového nářadí pamatujte na včasné dobíjení baterie po použití. V opačném případě může dojít k jejímu snadnému poškození.

Nabíjení baterie

PŘIBLIŽNÉ DOBY NABÍJENÍ S NABÍJEČKAMI	
4000 mAh	
4 A Rychlonabíječka (28086)	70 min.
2,4 A Rychlonabíječka (28085)	90 min.
8000 mAh	
4 A Rychlonabíječka (28086)	125 min.
2,4 A Rychlonabíječka (28085)	240 min.

VAROVÁNÍ

Před přípravou a používáním akumulátorového nářadí si přečtěte celý návod k obsluze a uchovejte jej u výrobku, aby se s ním mohl obsluha seznámit. Pokud výrobek někomu půjčíte nebo prodáte, přiložte k němu tento návod k obsluze. Zabraňte poškození tohoto návodu. Výrobce neodpovídá za škody nebo zranění způsobené používáním zařízení v rozporu s těmito pokyny.

Před použitím se seznamte se všemi ovládacími prvky a součástmi zařízení, stejně jako se způsobem jeho vypnutí, abyste jej mohli v případě nebezpečné situace okamžitě vypnout. Před použitím zkontrolujte, zda jsou všechny součásti pevně upevněny a zda žádná část zařízení, například ochranné kryty, není poškozena, nesprávně namontována nebo nechybí. Totéž platí pro nabíječku a její napájecí kabel.

Pokud je akumulátorové nářadí, baterie nebo nabíječka poškozená či nekompletní, nepoužívejte ji a zajistěte opravu nebo výměnu za originální díly.

Pro kontrolu stavu nabití baterie stiskněte tlačítko na baterii a podle počtu rozsvícených LED diod případně baterii dobijte s ohledem na očekávanou dobu provozu akumulátorového nářadí. Při plném nabití svítí všechny LED diody. Baterii lze nabíjet z jakéhokoli stavu nabití, aniž by došlo ke snížení její kapacity.

5. Nejprve vložte baterii do vodicích drážek dodané nabíječky.

6. Před připojením nabíječky ke zdroji elektrického proudu zkontrolujte, zda napětí v zásuvce odpovídá rozsahu 220–240 V ~ 50 Hz a zda nabíječka nemá poškozený napájecí kabel (např. izolaci), kryt nebo jinou část.

Pokud je nabíječka poškozená, nechte ji vyměnit za bezvadnou originální nabíječku od výrobce. K nabíjení baterie smí být použita pouze originální nabíječka dodaná výrobcem, jinak může použití jiné nabíječky způsobit požár nebo výbuch v důsledku nevhodných nabíjecích parametrů. Chraňte napájecí kabel nabíječky před poškozením.

7. Připojte nabíječku do zásuvky elektrického proudu.

Pro nabíječky 28085/28086 chargers


- během nabíjení je stav indikován zelenou blikající LED diodou vedle červené LED
- po úplném nabití svítí pouze zelená LED
- při abnormálním průběhu nabíjení blikají současně zelená i červená LED

Stav nabití baterie lze sledovat podle počtu rozsvícených LED diod na baterii, které se rozsvěcují během nabíjení. Vyhrazuje si právo změnit výše uvedenou signalizaci procesu nabíjení a dobíjení.

8. Po dokončení nabíjení nejprve odpojte nabíječku od zdroje elektrického proudu a poté vysuňte baterii z nabíječky stisknutím a podržením tlačítka na baterii.

Popis funkcí baterie

Zobrazení zbývající kapacity baterie



1. Indicator lamps 2. Check button

Indicator lamps			Remaining capacity
Lighted	Off	Blinking	
■	■	■	75% to 100%
■	■	□	50% to 75%
■	□	□	25% to 50%
■	□	□	0% to 25%
▬	□	□	Charge the battery.

Přípevnění nebo vyjmutí baterie



1. Button
2. Battery

Funkční popis

UPOZORNĚNÍ:


Před jakýmkoli nastavováním nebo kontrolou funkcí náradí se vždy ujistěte, že je náradí vypnuté a že je vyjmuta baterie.

Nastavení úhlu rukojeti

UPOZORNĚNÍ: Před zahájením práce se vždy ujistěte, že je rukojeť pevně zajištěna v požadované poloze.

UPOZORNĚNÍ: Nezatlačujte páčku pro odjištění rukojeti dolů současně se stisknutím spouště. Netahejte za spoušť při současném stlačení páčky a otáčení rukojeti. Nedodržení tohoto pokynu může způsobit poruchu náradí.

Úhel rukojeti lze nastavit do polohy 0°, -90° nebo 90° doleva či doprava. Pro změnu úhlu rukojeti otočte rukojeť při současném zatažení aretačního tlačítka, poté tlačítko uvolněte.



1. aretační tlačítko

Funkce hlavního vypínače

VAROVÁNÍ: Z důvodu vaší bezpečnosti je toto náradí vybaveno bezpečnostní pojistkou, která zabraňuje neúmyslnému spuštění. NIKDY nepoužívejte náradí, pokud se spustí pouhým stisknutím spouště nebo páčky bez použití bezpečnostní pojistky. Před dalším používáním vraťte náradí do autorizovaného servisního střediska k řádné opravě.

VAROVÁNÍ: NIKDY nefixujte bezpečnostní pojistku páskou ani nijak nevyřazujte její funkci.

VAROVÁNÍ: Před vložením baterie do náradí vždy zkontrolujte, zda spoušť a ovládací páčka fungují správně a po uvolnění se vrací do polohy „VYPNUTO“. Používání náradí s nefunkčním spínačem může vést ke ztrátě kontroly a k vážnému zranění.

UPOZORNĚNÍ:

Při přenášení nikdy nemějte prst na spoušti. Náradí by se mohlo neúmyslně spustit a způsobit zranění.

POZNÁMKA: *Netahejte za spoušť silou bez současného stisknutí bezpečnostní pojistky. Může dojít k poškození spínače.*

POZNÁMKA: Pokud není náradí po určitou dobu používáno, automaticky se vypne.

Aby se zabránilo neúmyslnému stisknutí spouště, je náradí vybaveno bezpečnostní pojistkou. Pro spuštění náradí jednou rukou stiskněte bezpečnostní pojistku a druhou rukou stiskněte spoušť. Otáčky náradí se zvyšují s rostoucím tlakem na spoušť. Pro zastavení náradí spoušť uvolněte.



1. Zamknout spoušť

2. Přepnout spoušť

Electric brake

This tool is equipped with an electric brake.

Montáž:

UPOZORNĚNÍ:

Před prováděním jakýchkoli prací na nářadí se vždy ujistěte, že je vypnuté a že je vyjmuta baterie.

UPOZORNĚNÍ:

Při výměně stříhacích nožů vždy používejte ochranné rukavice, aby nedošlo k přímému kontaktu rukou s noži.

UPOZORNĚNÍ:

Při výměně stříhacích nožů neodstraňujte mazivo z převodovky a klikového mechanismu.

Montáž a demontáž stříhacích nožů

UPOZORNĚNÍ:

Před demontáží nebo montáží stříhacích nožů nasadte ochranný kryt nožů.

UPOZORNĚNÍ:

Vyhnete se pokud možno práci ve velmi horkém počasí. Při práci s nářadím dbejte na svůj fyzický stav.

UPOZORNĚNÍ:

Dbejte na to, aby stříhací nože nepřišly do náhodného kontaktu s kovovým plotem nebo jinými tvrdými předměty. Nože by se mohly zlomit a způsobit zranění.

UPOZORNĚNÍ:

Zabraňte kontaktu stříhacích nožů se zemí. Nářadí by se mohlo odrazit a způsobit zranění.

UPOZORNĚNÍ:

Přílišné natahování při práci s plotovými nůžkami, zejména ze žebříku, je velmi nebezpečné. Nepracujte ve stoje na nestabilním nebo vratkém podkladu.

POZNÁMKA:

Nepokoušejte se s nářadím řezat větve silnější než 15 mm v průměru.

POZNÁMKA:


Nekácejte suché stromy ani jiné tvrdé objekty. Mohlo by dojít k poškození nářadí.

POZNÁMKA:


Při použití stříhacích nožů nestříhejte trávu ani plevel. Stříhací nože by se mohly do trávy nebo plevelu zamotat.

Použití


Držte nářadí oběma rukama, stiskněte spínací páčku, poté pohybujte nářadím směrem dopředu.



Při běžné práci nakloňte stříhací nože ve směru stříhu a pohybujte s nimi klidně a plynule rychlostí přibližně 3 až 4 sekundy na jeden metr.



Pro rovnoměrné zastřížení horní části živého plotu natáhněte provázek v požadované výšce a stříhejte podél něj.



ÚDRŽBA

UPOZORNĚNÍ:

Před zahájením kontroly nebo údržby se vždy ujistěte, že je nářadí vypnuté a že je vyjmuta baterie.

Čištění nářadí


Nářadí čistěte setřením prachu suchým hadříkem nebo hadříkem navlhčeným v mýdlové vodě a dobře vyždímaným.

POZNÁMKA:


Nikdy nepoužívejte benzín, technický benzín, ředidla, alkohol ani podobné látky. Mohlo by dojít ke změně barvy, deformaci nebo vzniku prasklin.

Údržba stříhacích nožů

Před zahájením práce nebo jednou za hodinu během provozu naneste na stříhací nože olej s nízkou viskozitou (strojní olej nebo mazací olej ve spreji).



Po ukončení práce odstraňte prach z obou stran stříhacích nožů drátěným kartáčem, setřete je hadříkem a poté znovu naneste olej s nízkou viskozitou (strojní olej nebo mazací olej ve spreji).



POZNÁMKA:

Neomývejte stříhací nože vodou. Mohlo by dojít ke korozi nebo poškození nářadí.


POZNÁMKA:

Nečistoty a koroze způsobují zvýšené tření nožů a zkracují dobu provozu na jedno nabití baterie.


Broušení stříhacích nožů

POZNÁMKA: Pokud jsou stříhací nože broušením výrazně deformované, vyměňte je za nové.

1. Vložte baterii do nářadí.
2. Zapněte nářadí tak, aby se horní a dolní nůž střídavě nastavily do pracovní polohy.




3. Vypněte nářadí a vyjměte baterii.
4. Vyšroubujte šroub a sejměte zachytávač větví.



1. Šroub 2. Zachytávač větví


5. Nastavte pilník do úhlu 45° a brousíte horní nůž pilníkem ze tří směrů.



45°

CAUTION: Before grinding the shear blades, make sure that the tool is switched off and the battery cartridge is removed from the tool.

6. Otočte nářadí spodní stranou nahoru a odstraňte otřepy ze stříhacích nožů pomocí pilníku.



7. Nastavte pilník do úhlu 45° a brousíte dolní nůž pilníkem ze tří směrů.

8. Vraťte nářadí do normální polohy a znovu odstraňte otřepy ze stříhacích nožů pilníkem.
9. Namontujte zpět zachytávač větví a upevněte jej šroubem.

Bezpečnostní upozornění pro akumulátorové plotové nůžky

1. Udržujte všechny části těla mimo dosah stříhacích nožů. Neodstraňujte posekaný materiál ani jej nepřidržíte, pokud se nože pohybují. Při odstraňování zaseknutého materiálu se ujistěte, že je nářadí vypnuté. Nože po vypnutí ještě krátce dobíhají. Okamžik nepozornosti může vést k vážnému zranění.
2. Plotové nůžky přenášejte za rukojeť pouze tehdy, když jsou stříhací nože zastavené. Správná manipulace snižuje riziko zranění.
3. Nářadí držte pouze za izolované úchopové plochy, protože stříhací nože mohou přijít do kontaktu se skrytým elektrickým vedením. Kontakt s vodičem pod napětím může způsobit úraz elektrickým proudem.
4. Nebezpečí: Udržujte ruce mimo dosah nožů. Kontakt s noži způsobí vážné zranění.
5. Nepoužívejte plotové nůžky v dešti ani ve vlhkém nebo velmi mokřém prostředí. Elektromotor není vodotěsný.
6. Uživatelům, kteří s plotovými nůžkami pracují poprvé, by měl zkušený pracovník ukázat správný způsob použití.
7. Plotové nůžky nesmí používat děti ani mladiství do 18 let. Výjimka může platit pro osoby starší 16 let, pokud jsou školeny pod dohledem odborníka.
8. Používejte plotové nůžky pouze v dobrém fyzickém stavu. Únava snižuje pozornost. Zvláštní opatrnost je nutná na konci pracovního dne. Pracujte klidně a soustředěně. Uživatel odpovídá za škody způsobené třetím osobám.
9. Nikdy nepoužívejte nářadí pod vlivem alkoholu, drog nebo léků.
10. Pevné kožené pracovní rukavice jsou základní součástí výbavy a musí být při práci vždy používány. Noste také pevnou obuv s protiskluzovou podrážkou.
11. Před zahájením práce zkontrolujte, zda jsou plotové nůžky v dobrém a bezpečném stavu. Nářadí nesmí být používáno, pokud není kompletně smontované.
12. Před zahájením práce se ujistěte, že stojíte na pevném a stabilním podkladu.
13. Při práci držte nářadí pevně.
14. Neprovozujte nářadí zbytečně naprázdno.
15. Pokud stříhací nože narazí na plot nebo jiný tvrdý předmět, okamžitě vypněte motor a vyjměte baterii. Zkontrolujte nože a v případě poškození je ihned opravte.
16. Před kontrolou nožů, odstraňováním závad nebo uvolňováním zachyceného materiálu vždy vypněte nářadí a vyjměte baterii.
17. Před prováděním jakékoli údržby vždy vypněte nářadí a vyjměte baterii.
18. Při přenášení plotových nůžek na jiné místo, včetně přerušení práce, vždy vyjměte baterii a nasadte kryt nožů. Nikdy nepřenášejte nářadí se spuštěnými noži a nikdy se nedotýkejte nožů rukama.

19. Po použití plotové nůžky, zejména nože, vyčistěte a před dlouhodobým skladováním je lehce naolejujte a nasadte kryt. Dodaný kryt lze zavěsit na zeď, což umožňuje bezpečné a praktické skladování.
20. Plotové nůžky skladujte s nasazeným krytem v suché místnosti, mimo dosah dětí. Nikdy je neskladujte venku.
21. Nikdy nemiřte stříhacími noži na sebe ani na jiné osoby.
22. Pokud se během práce nože zastaví kvůli cizím předmětům zachyceným mezi nimi, vypněte nářadí, vyjměte baterii a cizí předměty odstraňte pomocí nástrojů, například kleští. Odstraňování rukou může vést ke zranění, protože nože se mohou náhle pohnout.
23. Vyhněte se nebezpečnému prostředí. Nepoužívejte nářadí na vlhkých nebo mokřích místech a nevystavujte jej dešti. Vniknutí vody do nářadí zvyšuje riziko úrazu elektrickým proudem.
24. Nevyhazujte baterie do ohně. Mohlo by dojít k explozi. Dodržujte místní předpisy pro likvidaci.
25. Baterie neotevírejte ani nepoškozujte. Uvolněný elektrolyt je žíravý a může poškodit oči nebo pokožku, při požití může být toxický.
26. Nenabíjejte baterii v dešti ani na vlhkých místech.
27. Před zahájením práce zkontrolujte živé ploty a keře, zda neobsahují cizí předměty, jako jsou dráty nebo skryté elektrické vedení.

Obecné bezpečnostní pokyny pro elektrické nářadí

UPOZORNĚNÍ!

Je nutné si přečíst všechny bezpečnostní pokyny, provozní instrukce, obrázky a předpisy dodané s tímto nářadím. Nedodržení níže uvedených pokynů může vést k úrazu elektrickým proudem, požáru a/nebo vážnému zranění osob.

Veškeré bezpečnostní a provozní pokyny je nutné uchovat pro budoucí použití.

Pojem „elektrické nářadí“ použitý v následujících upozorněních označuje nářadí napájené ze sítě (s pohyblivým napájecím kabelem) nebo akumulátorové nářadí (bez pohyblivého napájecího kabelu).

1. BEZPEČNOST PRACOVNÍHO PROSTŘEDÍ

- a) Pracovní prostor musí být udržován v čistotě a dobře osvětlen. Nepořádek a tmavá místa často vedou k úrazům.
- b) Elektrické nářadí nesmí být používáno v prostředí s nebezpečím výbuchu, kde se nacházejí hořlavé kapaliny, plyny nebo prach. Elektrické nářadí vytváří jiskry, které mohou zapálit prach nebo výpary.
- c) Při práci s elektrickým nářadím udržujte děti a ostatní osoby mimo pracovní prostor. Rozptýlení může způsobit ztrátu kontroly nad nářadím.

2. ELEKTRICKÁ BEZPEČNOST

- a) Vidlice napájecího kabelu musí odpovídat zásuvce. Vidlice nesmí být žádným způsobem upravována. U nářadí s ochranným uzemněním nepoužívejte žádné adaptéry. Neupravené vidlice a odpovídající

zásuvky snižují riziko úrazu elektrickým proudem.

b) Nedotýkejte se uzemněných předmětů, jako jsou potrubí, radiátory, sporáky nebo chladničky. Pokud je vaše tělo uzemněno, zvyšuje se riziko úrazu elektrickým proudem.

c) Elektrické nářadí nevystavujte dešti, vlhkosti ani mokru. Vniknutí vody do nářadí zvyšuje riziko úrazu elektrickým proudem.

d) Napájecí kabel nepoužívejte k jiným účelům. Nářadí nepřenášejte ani netahajte za kabel a neodpojujte jej ze zásuvky tahem za kabel. Chraňte kabel před teplem, mastnotou, ostrými hranami a pohyblivými částmi. Poškozené nebo zamotané kabely zvyšují riziko úrazu elektrickým proudem.

e) Při práci venku používejte prodlužovací kabel určený pro venkovní použití.

f) Při použití nářadí ve vlhkém prostředí použijte proudový chránič (RCD). Použití RCD snižuje riziko úrazu elektrickým proudem.

3. OSOBNÍ BEZPEČNOST

a) Při práci s elektrickým nářadím buďte pozorní, soustředění a postupujte s rozvahou. Nepoužívejte nářadí, jste-li unavení nebo pod vlivem alkoholu, drog či léků. Okamžik nepozornosti může způsobit vážné zranění.

b) Používejte osobní ochranné pracovní prostředky. Vždy používejte ochranu očí. Ochranné pomůcky, jako je respirátor, protiskluzová obuv, ochranná přilba nebo ochrana sluchu, snižují riziko zranění.

c) Zabraňte neúmyslnému spuštění nářadí. Před připojením ke zdroji nebo vložením baterie se ujistěte, že je vypínač vypnutý.

d) Před zapnutím nářadí odstraňte veškeré nastavovací klíče nebo nástroje.

m) Pracujte pouze v dosahu, který umožňuje bezpečnou práci. Vždy udržujte stabilní postoj a rovnováhu.

e) Noste vhodné oblečení. Nenoste volné oblečení ani šperky. Dlouhé vlasy a oděv udržujte mimo pohyblivé části.

f) Pokud je nářadí vybaveno zařízením pro odsávání prachu, ujistěte se, že je správně připojeno a používáno.

g) Nedovolte, aby rutina vedla k podcenění bezpečnostních zásad. Neopatrná práce může způsobit vážné zranění během zlomku sekundy.

4. POUŽÍVÁNÍ A ÚDRŽBA ELEKTRICKÉHO NÁŘADÍ

a) Nepřetěžujte nářadí. Používejte správný typ nářadí pro danou práci.

b) Nářadí, které nelze zapnout nebo vypnout vypínačem, nepoužívejte.

c) Před nastavováním, výměnou příslušenství nebo skladováním odpojte nářadí od zdroje nebo vyjměte baterii.

d) Nepoužívané nářadí uchovávejte mimo dosah dětí.

e) Provádějte pravidelnou údržbu nářadí. Zkontrolujte pohyblivé části, praskliny a poškození.

f) Řezné nástroje udržujte ostré a čisté.

g) Používejte nářadí pouze k účelům, pro které je určeno.

h) Rukojeti a úchopové plochy udržujte suché, čisté a bez mastnoty.

5. POUŽÍVÁNÍ A ÚDRŽBA AKUMULÁTOROVÉHO NÁŘADÍ

a) Nabíjejte pouze nabíječkou určenou výrobcem.

b) Používejte pouze baterie určené pro dané nářadí.

c) Při nepoužívání chraňte baterii před kontaktem s kovovými předměty.

- d) Při nesprávném použití může z baterie unikat elektrolyt – vyhněte se kontaktu.
- e) Nepoužívejte poškozené nebo upravené baterie.
- f) Nevystavujte baterii ohni ani teplotám nad 130 °C.
- g) Dodržujte všechny pokyny k nabíjení.

6. SERVIS

- a) Opravy smí provádět pouze kvalifikovaný servis s použitím originálních náhradních dílů.
- b) Poškozené baterie se nesmí opravovat – výměnu provádí pouze výrobce nebo autorizovaný servis.

Bezpečnostní pokyny k nabíječce

- Chraňte nabíječku před deštěm a vlhkostí, používejte ji pouze v interiéru.
- Nabíječka je určena výhradně k nabíjení dodané baterie.
- Udržujte nabíječku čistou a před použitím zkontrolujte její stav.
- Neprovozujte nabíječku na hořlavých površích ani v prostředí s nebezpečím výbuchu.
- Při nabíjení zajistěte dostatečné větrání.
- Po dokončení nabíjení odpojte nabíječku ze zásuvky.
- Nabíječku nesmí používat osoby bez dozoru, pokud nejsou schopny bezpečného používání.

Bezpečnostní pokyny k baterii

- Skladujte a nabíjejte baterii v suchém prostředí.
- Nevystavujte baterii přímému slunci ani teplotám nad 50 °C.
- Nabíjejte pouze po dobu nezbytně nutnou.
- Chraňte baterii před nárazy, vlhkostí a mechanickým poškozením.
- Nikdy baterii nespalujte ani nevyhazujte do vody.
- Při úniku elektrolytu zabraňte kontaktu s pokožkou a očima.

Skladování

- Nářadí skladujte na suchém místě mimo dosah dětí.
- Před skladováním vyjměte baterii.
- Chraňte nářadí a baterii před mrazem, vlhkostí a vysokými teplotami.

Význam symbolů na štítcích



	Před použitím si přečtěte návod
	Používejte certifikovanou ochranu zraku a sluchu.
	Noste ochranné rukavice a chraňte ruce před zraněním.
	Nevystavujte dešti.
	Dodržujte bezpečnou vzdálenost.
	Pozor na odletující nečistoty.
	Splňuje příslušné požadavky EU.
	Stejnoseměrný proud / napětí
	Elektrický odpad
SN	Sériové číslo včetně roku a měsíce výroby.

Likvidace odpadu

OBALY

- Obaly vyhodte do příslušného kontejneru na tříděný odpad.

AKU NÁŘADÍ



Podle evropské směrnice (EU) 2012/19 se elektrická a elektronická zařízení nesmějí vyhazovat do smíšeného odpadu, ale je nezbytné je odevzdat k ekologické likvidaci do zpětného sběru elektrozařízení na k tomu určená sběrná místa. Před odevzdáním aku nářadí z něj odejměte akumulátor, který je nutné odevzdat k ekologické likvidaci baterií samostatně (odděleně). Informace o sběrných místech obdržíte na obecním úřadě.

AKUMULÁTOR



Akumulátor obsahuje náplně, které jsou nebezpečné pro životní prostředí, proto jej odevzdejte k ekologické recyklaci / likvidaci do zpětného sběru akumulátorů. Podle evropské směrnice o akumulátorech a bateriích 2006/66 EC nesmí být nepoužitelné akumulátory vyhozeny do smíšeného odpadu či životního prostředí. Informace o sběrných místech obdržíte na obecním úřadě.

Záruční lhůta a podmínky (práva z vadného plnění)

- Požádá-li o to kupující, je prodávající povinen kupujícímu poskytnout záruční podmínky (práva z vadného plnění) v písemné formě dle zákona.

ZÁRUČNÍ A POZÁRUČNÍ SERVIS

Pro uplatnění práva na záruční opravu zboží se obraťte na obchodníka, u kterého jste zboží zakoupili.

Likvidace odpadu

OBALY

- Obaly vyhodte do příslušného kontejneru na tříděný odpad.

AKU NÁŘADÍ



Podle evropské směrnice (EU) 2012/19 se elektrická a elektronická zařízení nesmějí vyhazovat do směsného odpadu, ale je nezbytné je odevzdat k ekologické likvidaci do zpětného sběru elektrozařízení na k tomu určená sběrná místa. Před odevzdáním aku nářadí z něj odejměte akumulátor, který je nutné odevzdat k ekologické likvidaci baterií samostatně (odděleně). Informace o sběrných místech obdržíte na obecním úřadě.

AKUMULÁTOR



Akumulátor obsahuje náplně, které jsou nebezpečné pro životní prostředí, proto jej odevzdejte k ekologické recyklaci / likvidaci do zpětného sběru akumulátorů. Podle evropské směrnice o akumulátorech a bateriích 2006/66 EC nesmí být nepoužitelné akumulátory vyhozeny do směsného odpadu či životního prostředí. Informace o sběrných místech obdržíte na obecním úřadě.

Záruční lhůta a podmínky (práva z vadného plnění)

- Požádá-li o to kupující, je prodávající povinen kupujícímu poskytnout záruční podmínky (práva z vadného plnění) v písemné formě dle zákona.

ZÁRUČNÍ A POZÁRUČNÍ SERVIS

Pro uplatnění práva na záruční opravu zboží se obraťte na obchodníka, u kterého jste zboží zakoupili.

EU Prohlášení o shodě

Výrobce Levior s.r.o. • Tovačovská 3488, CZ-750 02 Přerov prohlašuje, že následně označená zařízení na základě své koncepce a konstrukce, stejně jako na trh uvedená provedení, odpovídají níže uvedeným požadavkům Evropské unie. Toto prohlášení se vydává na výhradní odpovědnost výrobce.

Předměty prohlášení-identifikace výrobků:

Nůžky na živé ploty

Položka č.: 28630

Model No.: PLYL-09-20V

jsou ve shodě s následujícími harmonizovanými normami včetně jejich pozměňujících příloh, pokud existují, na jejichž základě se shoda prohlašuje s dále uvedenými harmonizačními předpisy:

2006/42/EC:

EN 62841-1:2015+A11

EN 62841-4-2 :2019+A1+A11

2014/30/EU:

EN IEC 55014-1:2021

EN IEC 55014-2:2021

Technická dokumentace (2006/42/EC a 2014/30/EU) je dostupná na adrese výrobce.

Místo a datum vydání EU prohlášení o shodě: Přerov, 15.12. 2025

Osoba oprávněná vypracováním EU prohlášení o shodě jménem výrobce

(podpis, jméno, funkce):

 **LEVIOR** s.r.o.

Tovačovská 3488/28, 750 02 Přerov

IČO 61973939 DIČ CZ61973939

tel.: 581 746 256-8, fax: 581 746 255



Ondřej Marek
jednatel společnosti Levior s.r.o.